

Horizontal Tank Tray Installation Instructions



Model PA-007 Horizontal Tank Tray (for inside use only)

Note: Model PA-007 tray is designed to accommodate the Vilco/Granby horizontal fiberglass tank (models 150, 175, 200 SWH) and the ROTH DWT 1500L. In all cases the tank must be located indoors and must be lifted and placed inside tray.

Steps

1. Sweep area where new tank is being installed. The area must be clean to insure no rocks or debris remain on the floor surface.
2. Position the PA-007 containment tray close to the final desired install location. The filter and alarm end (noted by the embossed Oil Yeller nameplate in the tray) should be oriented at the tank valve outlet end. (Vilco/Granby horizontal tanks)
3. For the ROTH 1500L tank the tank base shall straddle the midpoint rib.
4. Install kits are not required for these tank installations.
5. Lift the tank and install tank in tray. Center the tank and align per piping requirements.
6. Slowly pull on tray lip from each end to slide, move and position tank & tray in final install position.
7. Install piping connections and tighten fittings.
8. Insure filter and all burner supply piping connections are installed over tray area (horizontal tanks).
9. Prior to filling tank, check and adjust the tank in the tray. In some cases the tank moves when tightening the fill and vent pipe fittings.
10. For leak monitoring, choose one of three Oil Yeller leak detection alarms.