

## PA-009 Tank Tray Installation Instructions



### **Model PA-009 Tray for Granby 720 - 1000 litre, Vilco 125 G SW & Roth DWT 1000L & 1000LH**

Note: Model PA-009 tray is designed to accommodate the Granby 2 in 1 tanks model 720 & 1000 litres, Vilco 125 GS W and the ROTH DWT 1000L & 1000LH. In all cases the tank must be located indoors and must be lifted and placed inside tray.

#### **Steps (Note: for Vilco 125 G SW refer to PA-001 instruction sheet)**

1. Sweep area where new tank is being installed. The area must be clean to insure no rocks or debris remains on the floor surface.
2. Check the tray for damage prior to placing on the floor.
3. Position the PA-009 containment tray close to the final desired install location.
4. Install kits are not required for these tank installations.
5. Lift the tank and install tank in tray. Center the tank in tray and/or to desired location.
6. Slowly pull on tray lip from each end to slide, move and position tank & tray in final install position.
7. Install piping connections and tighten fittings.
8. Prior to filling tank, check and adjust the tank in the tray. In some cases the tank moves or shifts when tightening the fill and vent pipe fittings.
9. For leak monitoring, choose one of three Oil Yeller leak detection alarms.
10. Install filter over tank or at the burner using a PA-008 or PA-005 L-shape tray.